


Sensor Wash Assembly for Strantrol® 880 Transmitter and Strantrol® 890 Controller



Data Sheet

Water Technologies

SIEMENS

Technical Data


Make sure a hose clamp (provided) is used when installing the 3/8" O.D. vinyl tubing on the auto clean pump discharge port. This tube connects the pump discharge (bottom of pump) with the submersible sensor.

If the hose clamp is misplaced, use a small "tie wrap" for this purpose.



Hose Clamp

Sensor Wash Configuration (shown with Strantrol 880 Transmitter)



**DO NOT OPERATE THE AUTO CLEAN SYSTEM
UNLESS THE DISCHARGE TUBE IS PROPERLY SECURED!**

Siemens
Water Technologies

Germany
+49 8221 9040
wtger.water@siemens.com

United Kingdom
+44 1732 771777
wtuk.water@siemens.com

USA
+1 800 809 0971
stranco.water@siemens.com

© 2009 Siemens Water Technologies Corp.
Literature No.: ST.040.860.005.IE.DS.0709
Subject to change without prior notice.

Strantrol is a trademark of Siemens, its subsidiaries or affiliates.

The information provided in this literature contains merely general descriptions or characteristics of performance which in actual case of use do not always apply as described or which may change as a result of further development of the products. An obligation to provide the respective characteristics shall only exist if expressly agreed in the terms of the contract.